

## § 117.821

visual inspection shows that the channel is clear and there are no vessels transiting in the area. While the bridge is moving, the operator shall maintain constant surveillance of the navigation channel.

(e) Before closing the draw, the horn will sound five short blasts. Five short blasts of the horn will continue until the bridge is seated and locked down to vessels.

(f) When pedestrian traffic has cleared, the horn will sound one prolonged blast followed by one short blast to indicate the draw is opening to vessel traffic.

[CGD05-06-017, 71 FR 40420, July 17, 2006]

## § 117.821 Atlantic Intracoastal Waterway, Albermarle Sound to Sunset Beach.

(a) The drawbridges across the Atlantic Intracoastal Waterway in North Carolina shall open on signal for commercial vessels at all times and on signal for pleasure vessels, except at the times and during the periods specified in this paragraph:

(1) Onslow Beach Swing Bridge, mile 240.7, at Cap Lejeune, NC, between 7 a.m. and 7 p.m., the draw need only open on the hour and half hour.

(2) S.R. 50 Bridge, mile 260.7, at Surf City, NC, between 7 a.m. and 7 p.m., the draw need only open on the hour.

(3) Figure Eight Swing Bridge, mile 278.1, at Scotts Hill, NC, the draw need only open on the hour and half hour.

(4) S.R. 74 Bridge, mile 283.1, at Wrightsville Beach, NC, between 7 a.m. and 7 p.m., the draw need only open on the hour; except that from 7 a.m. to 11 a.m. on the third and fourth Saturday in September of every year, the draw need not open for vessels due to the Triathlon run.

(5) S.R. 1172 Bridge, mile 337.9, at Sunset Beach, NC, shall open on the hour on signal between 7 a.m. to 9 p.m.

(b) If a pleasure vessel is approaching a drawbridge which is only required to open on the hour or on the hour and half hour, and cannot reach the drawbridge on the hour or on the half hour, the drawtender may delay the required

## 33 CFR Ch. I (7-1-08 Edition)

opening up to 10 minutes past the hour or half hour.

[CGD05-97-072, 63 FR 9419, Feb. 25, 1998, as amended by CGD05-98-030, 63 FR 24427, May 4, 1998; USCG-1999-5832, 64 FR 34712, June 29, 1999; CGD05-05-102, 71 FR 5010, Jan. 31, 2006; USCG-2001-10881, 71 FR 70312, Dec. 4, 2006; CGD05-07-026; 73 FR 5093, Jan. 29, 2008]

## § 117.822 Beaufort Channel, NC.

The draw of the US 70 bridge, mile 0.1, at Beaufort, shall open as follows:

(a) From 6 a.m. to 10 p.m., the draw need only open every hour on the hour and on the half hour; except that Monday through Friday the bridge need not open between the hours of 6:30 a.m. to 8 a.m. and 4:30 p.m. to 6 p.m.

(b) From 10 p.m. to 6 a.m., the bridge shall open on signal.

[CGD05-01-001, 66 FR 40119, Aug. 2, 2001]

## § 117.823 Cape Fear River.

The draw of the Cape Fear Memorial Bridge, mile 26.8, at Wilmington need not open for the passage of vessel from 8 a.m. to 10 a.m. on the second Saturday of July of every year, and from 7 a.m. to 11 a.m. on the second Sunday of November of every year.

[CGD05-05-102, 71 FR 5010, Jan. 31, 2006]

## § 117.824 Neuse River.

(a) The draw of the U.S. 17 bridge, mile 33.7, at New Bern:

(1) Need not open from 6:30 a.m. to 8:30 a.m. and from 4:00 p.m. to 6:00 p.m., Monday through Friday, for pleasure vessels. However, the draw shall open at 7:30 a.m. and 5:00 p.m., for any vessel waiting to pass.

(2) Need not open from 2:00 p.m. to 7:00 p.m. from May 24 through September 8, on Sundays and Federal holidays, for pleasure vessels. However, the draw shall open at 4:00 p.m. and 6:00 p.m., for any vessel waiting to pass.

(3) Must always open on signal for public vessels of the United States.

(4) Shall open on signal at all other times.

(b) The draw of the Atlantic and East Carolina Railway bridge, mile 80.0 at

## Coast Guard, DHS

## § 117.833

Kinston, shall open on signal if at least 24 hours notice is given.

[CGD82-025, 49 FR 17452, Apr. 24, 1984, as amended by CGD5-88-054, 54 FR 3778, Jan. 26, 1989. Redesignated by CGD05-05-102, 71 FR 5010, Jan. 31, 2006 and amended by USCG-2001-10881, 71 FR 70312, Dec. 4, 2006]

### § 117.825 Newport River.

The draw of the Atlantic and East Carolina Railway bridge, mile 13.0 at Newport, need not be opened for the passage of vessels.

### § 117.829 Northeast Cape Fear River.

(a) The draw of the Isabel S. Holmes Bridge, at mile 1.0, at Wilmington, North Carolina will operate as follows:

(1) The draw will be closed to pleasure craft from 6 a.m. to 6 p.m. every day except at 10 a.m. and 2 p.m. when the draw will open for all waiting vessels.

(2) The draw will open on signal for Government and commercial vessels at all times.

(3) The draw will open for all vessels on signal from 6 p.m. to 6 a.m.

(4) From 8 a.m. to 10 a.m. on the second Saturday of July of every year, and from 7 a.m. to 11 a.m. on the second Sunday of November of every year, the draw need not open for vessels.

(b) The CSX Hilton Railroad Bridge, mile 1.5 in Wilmington, NC shall operate as follows:

(1) The draw of the bridge to be remotely operated by the controller at the Navassa Railroad Bridge mile 34.0 across the Cape Fear River.

(2) The draw shall be left in the open position to vessels and will only be closed for the passage of trains and to perform periodic maintenance authorized in accordance with Subpart A of this part.

(3) Trains shall be controlled so that any delay in opening of the draw shall not exceed ten minutes except as provided in 117.31(b).

(4) The CSX Hilton Railroad Bridge shall not be operated by the controller at the CSX Navassa Railroad in the event of failure or obstruction of the motion sensors, laser scanners, video cameras or marine-radio communications. In these situations, a bridge tender must be called to operate the bridge on-site.

(5) When rail traffic has cleared, the horn will automatically sound one prolonged blast followed by one short blast to indicate that the CSX Hilton Railroad Bridge is moving to the full open position to vessels. During open span movement, the channel traffic lights will flash red, until the bridge is in the full open position to vessels. In the full open position to vessels, the bridge channel traffic lights will flash green, allowing vessels to pass safely.

(6) During closing span movement, the channel traffic lights will flash red, the horn will sound five short blasts, and an audio voice-warning device will announce bridge movement. Five short blasts of the horn will continue until the bridge is seated and locked down. When the bridge is seated and in the locked down position to vessels, the channel traffic lights will continue to flash red.

(c) The draw of the Seaboard System Railroad Bridge across the Northeast Cape Fear River, mile 27.0, at Castle Hayne, North Carolina shall open on signal if at least four hours notice is given.

[CGD05-02-014, 67 FR 70554, Nov. 25, 2002, as amended by CGD05-04-120, 69 FR 70061, Dec. 2, 2004; CGD05-05-102, 71 FR 5010, Jan. 31, 2006]

### § 117.831 Pamlico and Tar Rivers.

The draws of the US17-264 bridge, mile 37.2 at Washington, and the Boyds Ferry bridge, mile 44.8 at Grimesland, shall open on signal if at least 24 hours notice is given. The bridge owners shall restore constant attendance when so directed by the District Commander.

### § 117.833 Pasquotank River.

(a) The draw of the Albemarle & Chesapeake railroad bridge, mile 47.7, at Elizabeth City, North Carolina, shall be maintained in the open position; the draw may close only for the crossing of trains and maintenance of the bridge. When the draw is closed, a bridgetender shall be present to reopen the draw after the train has cleared the bridge.

(b) The draw of the US 158 Highway Bridge, mile 50.7, at Elizabeth City, shall open on signal; except that between 7 a.m. and 9 a.m., and 4 p.m. and 6 p.m., Monday through Friday, the draw need open only at 7:30 a.m., 8:30